

## > CABLE KIT



## ASSEMBLY INSTRUCTIONS

### CABLE KIT / WALL MOUNTED SWIVEL KIT

- 1) Fix the **Top boss** into ceiling using the provided **Screw**.
- 2) Insert **Upper cable clamp** into **Top boss**, then secure the two screws with the Allen key, to fix it into the **Top boss**.
- 3) Fix the **Floor anchor** (aligned with the Top boss) into the floor, using the provided **Screw**.
- 4) Pass the cable through the **Adjusting sleeve**, the Spring, the ring and the **Locking ring**. Stretch the cable manually close the **Floor anchor** and then cut it with a wire-cutter so it could reach halfway up to the **Floor anchor** (Mark A).
- 5) Leave 1/4 " clearance between the bottom of the lower **Universal grip** and the top **Floor anchor**, fix firmly the lower **universal grip** with the provided screw.
- 6) Fix the **Adjusting sleeve** into the **Floor anchor** with the provided screw, without over-tightening it.

In case of an assemblage on rails (ceiling and floor) use 2 rails fixings instead of the screw provided with the rod kit.

